

Use instructions

For freezer

(Please read the instructions
carefully before using)

Respected customers

Thank you for choosing and using our display cabinet series products. To facilitate your faster use, understand this

Please read this manual carefully and keep it properly for reference at any time.

1. The product appearance design leads the market trend, the modelling is unique, the display area is big, the display effect is good, beautiful and generous, the movement is convenient, suits each type demand of the market.
2. Product parts procurement layer by layer control, strict requirements for suppliers; key components selected domestic well-known brands.
3. The company's series of products using toughened reflective coating glass, high transparency, good display effect, good insulation performance.
4. The company's series of products using high-quality waterproof lamp, soft and natural lighting, to ensure the color of the product bright.
5. The company's series of products refrigeration fast, electricity saving, cost-effective, suitable for various places to use.
6. The company's series of products using automatic / manual temperature control technology, simple and convenient to use, digital tube / LCD screen display temperature more intuitive.

Important note

- 1、 In order to prevent electric shock and other hazards, do not let the machine rain or damp, do not disassemble the machine without authorization.
2. We reserve the right to change the design of all series of products.

Attention

- 1、 Please place the machine horizontally without tilting; the normal use voltage is 220-240 V/50HZ single AC, equipped with special three-hole plug (250 V 16A) and 16 A fuse, must have reliable ground wire device.
- 2、 Do not share with other electrical appliances and use a common socket, no will cause electric shock, short circuit, line heating, so as not to cause fire.
- 3、 It is forbidden to wash the surface of the freezer directly with water to avoid electric shock casualties。
- 4、 When plugging the power cord plug, the hand should keep dry and clean and hold the plug to unplug, do not pull the wire, do not let the weight press the power cord, so as not to cause leakage, fire。
- 5、 It is forbidden to place flammable, explosive and volatile dangerous goods in the cabinet, and to store acid and alkali with strong corrosion。

- 6、 If the power supply is interrupted or the thermostat stops at least 5 minutes before electrification, so as not to damage the compressor. If the voltage is unstable, please provide a voltage regulator of more than 4000 W。
- 7、 Be in a well-ventilated position. There should be 50 cm space around the freezer for ventilation and refrigeration performance。
- 8、 Ambient temperature of our products should be °C10-32。
- 9、 After using the freezer for a period of time, if it is stopped for a long time,, you should unplug the power supply, clean up the contents of the cabinet, so as not to corrode the inner wall plate of the cabinet, and run 2-3 hours every 2 months。
- 10、 For Y type connectors, instructions should include the following: if the power supply is damaged, to avoid danger, it must be replaced by the manufacturer or by a professional。
- 11、 The company's series of products for household appliances and similar purposes, in line with GB4706.1GB4706.13GB17625.1 and other national mandatory inspection standards, has passed the ISO9001 quality management system certification, ISO14001 environmental management system certification, ISO45001 occupational health and safety management system certification。
- 12 Note: outdoor use, please add sunscreen, no will affect the refrigeration effect。

Direction for use

- 1、 The freezer must be thoroughly cleaned before use。
- 2、 Use voltage 220-240 V 50HZ single-phase AC, if voltage instability, if voltage instability, please equipped with more than 4000 W voltage regulator。
- 3、 For the first time, the empty box should run for 4-6 hours before the temperature is cooled evenly and then put into the food
- 4、 Power indicator when red light, compressor running light when green light。
- 5、 The temperature in the freezer can be adjusted by the thermostat. When rotating clockwise, the temperature in the freezer decreases and vice versa。
- 6、 Our products are display cabinets, not suitable for storage of articles。
- 7、 One-time addition of items should not be too much, should gradually increase the amount of storage, items and articles should have a certain gap, so that air conditioning flow, uniform temperature, to ensure product quality。
- 8、 Under the glass door 120 mm range is the temperature instability area, the temperature $\geq -12^{\circ}\text{C}$, please store according to the food requirements。

keep in good repair ;

- 1、 Please unplug the plug before cleaning for your safety。
- 2、 Always use soft cloth or sponge spray non-corrosive cleaning agent to wipe the display cabinet。

If the display cabinet is used for too long, the power plug should be unplugged to clean up the contents of the cabinet, and the external condenser should be cleaned irregularly in order to improve the refrigeration performance

The following are not failures

- 3、 The freezer made a clatter of water at work。
- 4、 Rainy weather or excessive air humidity, cold glass door water droplets。
- 5、 Compressor or condenser heating or ironing。
- 6、 When winter or ambient temperature is too low, the compressor does not start。

Simple Fault Analysis

fault phenomenon	cause	Exclusion methods
The compressor is not energized Normal work	Power cord plug contact Bad, loose; Small diameter or line Long; voltage too low or Too high	Repair or replacement of power supply: line Adjust supply voltage
Compressor continuous operation No downtime	The door seal is not tight or opens too frequently; the t adjusts improperly; Poor external ventilation; pu Too much food or too dense direct sunlight or nearby Heat source	Close doors, minimize Number of open doors; minimize Put in physical quantity; avoid direct sunlight or heat source Good external ventilation; temperature Proper position control
Too much noise	Uneven box A part of the cabinet is walle Touch external objects	Smooth placement Adjust freezer position

Controller description :



technical parameters :

function declaration	Scope	Factory setting	unit
Refrigeration sh temperature		-22	°C
Temperature return		4	°C
Temperature range	+15- -25	-22	°C
Time delay		3	minute; min

Key Description:

Light Key:

Press the light key to light up, then press the light key to extinguish the light.

Adjust key:

After power on, press the adjustment key display screen to flicker and display the set stop temperature, then press the adjustment key to set the stop temperature, after the adjustment is completed without any 3-5 automatically save, and restore to the current box temperature.

Direction for use :

The controller display displays the current temperature in the box temperature inside the box, and countdown 3 minutes delay start, delay light flashing, after the delay end, compressor, cooling fan start, when the temperature inside the box reaches the set stop temperature, compressor, cooling fan stop working, when the temperature inside the box is higher than the set start-up temperature, and start-up time and the last stop time must be more than 3 minutes, compressor, cooling fan start again Work.