

Humidifier manual

How to add water

It is recommended to use clean tap water or purified water, and there are three ways to add water:

Method 1: Add water directly to the top. Add an appropriate amount of water from the concave surface of the water tank cover using a water cup.

Method 2: Remove the lid and add water. Open the water tank cover and add water to the tank.

Method 3: Lift the water tank and add water. Place the water tank on a horizontal tabletop. Add water to the water tank; Or lift the water tank directly to the faucet, clean it first, and then add water

Do not exceed the upper limit of water addition.

How to use

1. Connection: Connect the humidifier power plug to the three pin plug inside the cabinet
2. Power on: Rotate the knob clockwise.
3. Shutdown: Turn the forward button counterclockwise to "o"
4. Adjust the fog output: Rotate the knob clockwise to increase the fog output, and counterclockwise to decrease the fog output.

5. Description of Display Lamp Status

Normal operation - the white light keeps on

Water shortage - the red light keeps on

Lift the water tank - the red light keeps on

Shut down - turn off

Maintenance

1. The shell can be wiped clean with a soft cloth directly.
2. It is recommended to clean the filter and water tank at least once a month. If there is scale in the water tank, you can pour citric acid into the tank, then use a cotton swab or soft bristled brush to wipe off the scale, and then rinse with water.
3. When the humidifier is not used for a long time, it is recommended to pour out the remaining water in the base and water tank, dry all components, and then store them.

Attention

1.Regarding the water tank.

Never inject hot water above 40 °C into the water tank

Never let water pour into the mist outlet

When the room temperature is below 0 °C, please pour out the water in the water tank to avoid freezing and causing damage to the machine.

Do not put metals, chemicals, or detergents into the water tank for use.

When pouring out the water from the tank, please turn off the machine first.

2.If the product produces abnormal noise, odor, or high temperature during use, please stop using immediately.

Do not bring hair, fabrics, etc. close to the machine to avoid getting stuck or blocking the air inlet and outlet